1. Remove ring holding light in place
2. Remove the light from the machine and disconnect wiring
3. This light may be installed as either high or low beam. Install wiring connector accordingly to the desired beam (see diagram below).
4. Connect the hot wire from the machine to the desired terminal on the connector. Connect the ground to ground. The third unused wire may be installed into the connector to prevent short circuits.
5. Install the light and secure the ring using the new screws provided.