



- 1) Remove the dome light cover, speaker covers, hardware, and outside trim pieces.
- 2) Leaving the fiberglass shell in place, remove old foam and scrape out old glue.
- 3) Vacuum dust, foam, and glue scrapings.
- 4) Carefully remove all $\frac{3}{4}$ " plastic screw spacers. Should be able to leave the 2" spacers in place.
- 5) Reinstall short plastic screw spacers that are provided. These must be used for proper installation.
- 6) Install heater knob side first to ensure the heater knob does not get damaged.
- 7) Align post and headliner holes for proper positioning.
- 8) Install screws along front and back of headliner.
- 9) Replace dome light cover.
- 10) Replace all covers.