


Instructions for installation of the HC830411 Steering Pin & Block Kit using this Reamer Tool:

- 1. Do not use on a bore that has been previously welded
- 2. Turn reamer with a ½" slow speed drill
- 3. Ream slowly and check the pin fit frequently to avoid going too deep



## **Reamer Return Instructions**

1. Return reamer withing 45 days to:

Hy-Capacity P.O. Box 156 Humboldt, IA 50548

- 2. Reamer will be inspected for damage and if found in usable condition, the \$500.00 rental charge will be credited to your account
- 3. After 45 days or if damaged tool is received, no credit will be issued