



8302354 – Hydraulic Breakaway Coupler Kit

Instruction Guide



1. Take the plastic caps off couplers (A).
2. Install dust caps (B) on couplers by pushing them on until it snaps in the groove.
3. Remove jam nuts (C) from couplers (A).
4. Install couplers (A) into the bracket (D). JIC threads pointing away from the bracket.
5. Re-install & tighten jam nuts (C) on the couplers (A).
6. Mount coupler assembly on tractor bracket using (2) 1-1/4" bolts (E). If using the spacer (F), use the (2) 2" bolts (G).
7. Measure the hydraulic hose fitting on the tractor.
 - a. If 3/4" JIC thread, install fitting (H) onto the JIC of coupler (A).
 - b. If 7/8" JIC thread, install hydraulic hose on the JIC of coupler (A).

| Kit Contents | |
|--------------|------------------|
| A | Couplers (2) |
| B | Dust Caps (2) |
| C | Jam Nuts (2) |
| D | Bracket (1) |
| E | 1-1/4" Bolts (2) |
| F | Spacer (1) |
| G | 2" Bolts (2) |
| H | Fitting (2) |

