



HA353657A1 SET | CREE LED Flood/Spot Combo Cab Roof Light Set, 4800 Lumens – (Pkg. of 2)

Instruction Guide

1. Remove original light and bezel from the machine
2. Remove lights from bezel and disconnect electrical connector
3. Place the Hy-Cap lights into the bezel from the front
4. Secure by inserting the 4 cap screws (provided) from the rear
5. Attach electrical connectors
6. Replace bezel (with lights intact) onto machine and secure hardware

