



## HF86036069 [LED Flood Beam w/Wiring Harness, 3000 Lumens]

### Instruction Guide

1. Remove original light from bracket
2. Align the mounting hole on new light with holes in u-shaped bracket and insert bolt. Attach washer and nut and secure tightly
3. Attach electrical connector
4. Light can be adjusted and aimed in desired direction by loosening cap screws in the mounting system

