

## HF87529726 KIT [Hy-Capacity LED Hi-Lo Beam Light, 13200 Lumens]

Instruction Guide

- 1. Apply a penetrating fluid to all nuts. Allow time to soak before removing nuts.
- 2. Disconnect electrical connections
- 3. Carefully remove nuts or hardware holding the lights in place. May be difficult to remove due to rust be cautious to not twist mounting bolts.
- 4. Remove OE light housing from hood.
- 5. Place new light into hood
- 6. Secure new light with hardware provided
- 7. Attach electrical connections as needed









