



HM4288656 [CREE LED Flood Beam Rear Cab Light, 1680 Lumens]

Instruction Guide

This lamp is designed to accommodate left & right, front & rear applications

1. Remove the original light from the machine
2. Disconnect electrical connector from light
3. Place new light into OE bracket on machine and replace bolt, washer & nut
4. Attach electrical connector
5. Adjust beam to desired position and secure hardware

