



## HR19075 [CREE LED Flood Beam Cab Roof Light, 1890 Lumens]

### Instruction Guide

1. Remove original light from mounting arm by loosening bolt (B)
2. Remove brackets (A) from original light and install them on the new LED light as shown
3. Attach light and bracket to original mounting arm
4. Install electrical connector as desired (included). If possible, place connection under cab roof (C)
5. Aim beam to desired location and tighten the bolts

