



## HR48989 [CREE LED Flood Beam Light, 3150 Lumens]

### Instruction Guide

1. Remove original light and bracket from fender & disconnect electrical connector (Protective covering under fender may need removed)
2. Install new bracket using hollow bolt and hardware provided
3. Install light into bracket and feed wires through bolt in fender
4. Install electrical connector
5. Attach the connector ends, adjust light to desired direction and secure all hardware

