



HR68473 [CREE LED Flood Beam Rear Fender Light, 3150 Lumens]

Instruction Guide

1. Remove original light and mount
2. Install new light with dampening washer and spacer in place as shown
3. Install electrical connector
4. Aim light to desire direction and tighten

