



SD830774 [Low Back Seat, Black Vinyl]

Instruction Guide

1. Insert a 1/4" x 1/2" bolt through the bracket and the seat bracket and fasten with a 1/4" locknut
- NOTE:** All bolts should be left loose until assembling is complete
2. Insert a 5/16" x 1/2" bolt with flat washer through the backrest bracket and fasten to the threaded hole in the seat bracket. Install the seat cushion with two 5/16" x 5/8" cap screws and lock washers. Install the backrest cushion by using a pair of the top two set of holes on the backrest and two 5/16" x 5/8" cap screws and lock washers
 3. Insert two 5/16" x 1/2" bolts with flat washers through the armrest bracket. Fasten the bolts to the threaded holes on the backrest bracket
 4. Insert a 5/16" x 5/8" bolt with flat washer through the armrest bracket and the backrest bracket. This bolt is fastened to the threaded hole in the seat back
 5. Assemble the right-hand brackets in the same order the left-hand brackets were assembled
 6. Tighten all bolts securely

