



## SM30082BU [Cushion Set, Gray & White Vinyl, Unassembled w/Brackets – (2 pc.)]

### Instruction Guide

#### Items Included:

- (4) 3/8" x 1-1/2" Bolts      (6) 3/8" x 3/4" Bolts      (10) 3/8" Lock Washers  
(2) 5/16" x 3/4" Bolts      (2) 5/16" Lock Washers

1. Place side brackets (angled out) on each side of seat
2. Using four 3/8" x 1-1/2" bolts with lock washer, place wood spacer between seat and bracket. Finger tight all four bolts (both sides of seat)
3. Using four 3/8" x 3/4" bolts with lock washers, attach lower back to brackets
4. Using two 3/8" x 3/4" bolts with lock washers, attach upper back bracket to center of lower back
5. Using two 5/16" x 3/4" bolts with lock washers, attach upper back to bracket
6. Make sure all bolts are tight

