



## F8149NU [13" Diaphragm Clutch Unit - New]

Instruction Guide

**When installing a new Ford Diaphragm PPA, you must install .040 shims between the backplate and flywheel**

