
Please pay special attention to the following when you install this clutch:

There are three small nuts under the end of the levers. Please take them out after finishing installation of the pressure plate to flywheel.







After Installation Nut is removed