



8302293 [CREE LED Flood Beam Light, 3400 Lumens]

Instruction Guide

1. Disconnect and remove original equipment light from machine
2. You can either remove the original light bracket from the machine OR use the bracket supplied with the light
 - a. If using the OE bracket, this Hy-Cap light will fit directly into the OE bracket with the use of two spacers (included with light)
 - b. If using Hy-Cap bracket that comes with light, remove entire OE bracket from machine (Best option for cab mounted lights is to use the OE bracket. This prevents the need to remove the cab roof for installation)
3. Attach electrical connector
4. Adjust light to desired location and secure hardware

