



HA87313315 [CREE LED Flood Beam Light, 3200 Lumens]

Instruction Guide

This light is designed to accommodate left or right-side applications

1. Remove the original light from the bracket (Do not remove bracket from grabrail)
2. Disconnect electrical connectors. Some machines may have connectors that are far inside the grabrail and cannot be easily reached. In these situations, you may need to clip the wires where you can access them and install the mating connectors (included with light)
3. Place the new Hy-Capacity light into the bracket (Some applications may require use of nylon spacers (included with light))
4. Insert bolt with washers and nut
5. Adjust light beam to desired location and secure all hardware

