



## HF9706418 [LED Flood Beam Light, 3500 Lumens]

### Instruction Guide

1. Remove original light from machine and disconnect wiring harness
2. Remove bracket from machine
3. Install new Hy-Cap bracket using hardware supplied
4. Attach wiring harness on new Hy-Cap light to harness on machine  
(Mating connector is supplied with light & may need to be installed onto machine wires)
5. Install new Hy-Cap light to Hy-Cap bracket
6. Adjust light to desired position and secure all hardware

