




# R101807 [John Deere Industrial Hydraulic Pumps]

Instruction Guide



<b>R101288</b>	<b>4 CI</b>
A. Suction	1-5/16"
B. Suction	1-5/8"
C. Pressure Port	1-1/16"
D. Cooler Port	7/8"
<b>R13426</b>	<b>4 CI</b>
A. Suction	1-1/16"
B. Suction	1-5/8"
C. Pressure Port	1-1/16"
D. Cooler Port	7/8"

<b>R101807</b>	<b>3 CI</b>
A. Suction	1-1/16"
B. Suction	1-5/8"
C. Pressure Port	1-1/16"
D. Cooler Port	7/8"