



S8301326 [Bucket Seat, Yellow Vinyl]

Instruction Guide

As with servicing any product, certain hazards exist. Use caution and common sense when using hand tools and adhere to all safety procedures. Always wear safety glasses.

The seat must only be installed by properly skilled and trained personal who are familiar with local rules and regulations. The engine switch must be off, ignition key removed, parking brake applied, and wheels blocked. If an operator presence switch is to be added, it is recommended that the battery be disconnected during its installation.

When fitting the seat to the equipment, remove the bolts/nuts holding the existing seat in place. These bolts can be re-used provided they are in good condition. If the bolts are rusting or in any way damaged, discard them and use new ones in accordance with the equipment manufacturer's recommendations. It is recommended that at least four 5/16-18" bolts be used to mount the S8301326 seat. The recommended dynamic torque is 80+/-15in-lbs. for bolting into the bottom mounting nuts in the plastic shell. Do not operate the equipment if the seat is not securely fastened according to the equipment manufacturer's specifications.

FORE/AFT ADJUSTERS

If the seat is to be installed with fore/aft adjusters, mount the adjusters to the seat bottom using the mounting bolts described above. Orient the adjuster handle to properly project out from the front side of the seat. This handle can be used to unlock the adjusters, which will allow the seat to slide backwards and forward to a comfortable latched position for the operator. Check to ensure that the seat does not strike any part of the cab or any of the controls as it's moved through the full fore/aft stroke. Ensure the seat is locked in place before operating the equipment. Do not operate the adjusters while the equipment is operating. Do not operate the equipment if the adjusters are loose, broken, or malfunctioning.

OPERATOR PRESENCE SWITCH

If the seat is fitted with an Operator Presence Switch, ensure the correct switch is being installed and make sure not to place a strain on the connecting wires or the switch. It is recommended that the battery be disconnected during the OPS switch installation. Ensure that the correct connections are fitted to the wires and that all the connections are secure and will not become damaged while using the equipment. Check for proper operation of the switch as described by the equipment manufacturer. If the equipment has an operator presence switch, do not operate the equipment if the switch is not properly functioning.

ARMRESTS

If installing armrests, follow the instructions included in the armrest kit. Armrests are not meant to be sat or stood on. To do so creates a hazard and an unsafe condition. Only operate the equipment from a fully seated position. **Do not sit or stand on the armrest!**



S8301326 [Bucket Seat, Yellow Vinyl]

Instruction Guide

SEAT BELTS

Mount the seat belts in accordance with equipment manufacturer's recommendations, all local rules and regulations, and the instructions included in the seat belt kit. If the vehicle is not Equipped with Roll-Over Protection Structures, seat belts should not be installed, Seats are component parts, so check with your local authorized dealer for your equipment before installing seat belts. It is the purchaser's responsibility to ensure the proper mounting and use of the seat and seat belts.

It is the customer's responsibility to ensure that the seats are proper for fitness and use in the application. Use of common sense and strict adherence to all safety belt procedures is required to be safe from injury or death.

