



TX12806U [10" Dual Stage Clutch Unit - New]

Instruction Guide

Setting Instructions for TX12806U – These units are not preset!

Before mounting to flywheel, loosen adjustments to high point, then adjust as explained below

When the clutch is mounted to the flywheel with the pins in place, the lever height should measure 1.5" from the top of the lever (where the bearing rides) down to the shoulder of the disc hub (where the rivets come through)

On PTO adjustment, the gap between Cam and Bolt should measure .030"

