Due to damages that may occur in shipping, we do not bolt the separator plate to pressure plate assembly

Use three bolts included to bolt separator plate to cover assembly

