

- 1. Remove OE light by removing 3 screws holding it in place
- 2. Disconnect wiring connector from machine
- 3. Place new Hy-Cap light into place and secure with 3 screws
- Attach electrical connector to machine connector (NOTE: This light includes a jumper harness to adapt to the OE connector on the machine. If at first the light does not power, reverse the jumper connector to resolve.)

