




# HD71361805 [Bridgelux LED Hi-Lo Beam Light, 3500 Lumens]

## Instruction Guide

1. Remove original light from machine
2. Remove rubber grommets & bushings from original bezel for use in new light bracket
3. Install OR rubber bezels & bushings into mounting holes on new light
4. Install electrical connector

The new Hy-Capacity light is originally dual beam. You have the option of using either high or low beam. OE wiring on your machine will allow for one beam only, so Hy-Capacity has provided a second connector for wiring installation. Simply connect the wire ends and insert them into housing in the desired position (high or low beam). The housing will provide protection of the unused spade. Follow the diagrams below to install the connector using desired beam



5. Install new light onto machine

