

8890118 [Inline Receiver Drier]

Instruction Guide

This Receiver Drier has “TOP” stamped on the outlet side to ensure correct installation.

Be aware that the sight glass may not face the same way the stamp indicates. Do not position the Receiver Drier based off the location of the sight glass, but rather by the location of the “TOP” stamp. The sight glass is only used with R12.

The illustration below shows how a pipe cleaner can be used and inserted into the outlet side. If the pipe cleaner is slightly bent toward the 6 o’clock position, the Receiver Drier has been mounted correctly.

